


Media Loading
紙捲安裝
紙卷安裝
Instalación de papel
Chargement de papier
Laden des labelmaterials
Instalação de etiquetas
Caricamento carta
Baskı malzemesini takma
Установка этикет ленты



The user is cautioned that any changes or modifications not recommended by Argox Information Co. Ltd. could result in the loss of the user's authority to operate the equipment. To ensure compliance, the users must use accessories and peripherals approved by Argox Information Co. Ltd.



Supplemental Information: This device complies with the requirement of FCC Part 15 Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference and
(2) This device must accept any interference received, including interference that may cause undesired operation.

INDUSTRY CANADA NOTICE:

This device complies with Industry Canada ICES-003 class A requirements.
Cet équipement est conforme a ICES-003 classe A de la norm Industrielle Canadian.



The manufacturer declares under sole responsibility that this product conforms to the following standards or other normative documents:
EN 62368-1:2020/A11:2020



Argox Information Co., Ltd certifies that the following products and/or components are compliant with the current requirements of the European Union Restriction on the use of Hazardous Substances (RoHS) Directive, 2011/65/EU, (EU)2015/863.



UL 62368-1, 3rd Ed.

警告使用者:
本產品為甲類資訊產品,為避免電磁干擾,本產品不應安裝或使用於住宅環境。

Argox Information Co., Ltd.
8F., No. 28, Baogao Rd., Xindian Dist.,
New Taipei City 231, Taiwan (R.O.C.)
Tel: +886-2-8912-1121 Fax: +886-2-8912-1124
<https://www.argox.com>
<https://www.youtube.com/user/argoxmkt>
email:service@argox.com

Copyright © 2025. Argox Information Co.Ltd., All Rights Reserved.

設備名稱：印表機 Equipment name	型號（型式）：OS-2130D Pro（系列型號如下） Type designation (Type)					
	受管物質及其化學符號 Restricted substances and its chemical symbols					
單元 Unit	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr ⁶⁺)	多溴聯苯 Polybrominat ed biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷電路 板組件	—	○	○	○	○	○
機殼	—	○	○	○	○	○
線材	○	○	○	○	○	○
變壓器	—	○	○	○	○	○
印字頭模組	—	○	○	○	○	○

備考 1: “超出0.1 wt %”及“超出0.01 wt %”係指限用物質之百分比含量超出百分比含量基準值。
Note 1: “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.
備考 2: “○”係指該項限用物質之百分比含量未超出百分比含量基準值。
Note 2: “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.
備考 3: “—”係指該項限用物質為排除項目。
Note 3: “—” indicates that the restricted substance corresponds to the exemption.








OS-2130D Pro Printers Quick Installation Guide

快速安裝指南
快速安裝指南
Guía Rápida
Rapide guide
Bedienerhandbuch
Impressora Guia de instalação rápida
Guida Rapida
Mini Kılavuzu
Руководство по быстрой установке



Part No: 49-20302-021
Revision Date: Jan. 2025



English

- A-**
- 1 Top Cover
 - 2 Paper Outlet
 - 3 Cover Lock
 - 4 Power Indicator
 - 5 Ready Indicator
 - 6 Feed Button
 - 7 Power Switch (O=Off, I= On)

- B-**
OS-2130D Pro
- 1 Cash Drawer Port
 - 2 Power Jack
 - 3 USB
 - 4 RS-232 Serial

- C-**
- 1 Media Hanger
 - 2 Release Levers
 - 3 Thermal Print Head
 - 4 Media Guides

繁體中文

- A-**
- 1 上蓋
 - 2 出紙孔
 - 3 上蓋開關
 - 4 電源燈
 - 5 確認燈
 - 6 送紙鍵
 - 7 電源開關 (O=關, I=開)

- B-**
OS-2130D Pro
- 1 錢櫃插槽
 - 2 電源連接插槽
 - 3 USB 埠
 - 4 RS232 串列埠

- C-**
- 1 紙捲供應端
 - 2 閉鎖卡條
 - 3 印字頭模組
 - 4 紙張器

简体中文

- A-**
- 1 上盖
 - 2 出纸孔
 - 3 上盖开关
 - 4 电源指示灯
 - 5 确认灯
 - 6 送纸按钮
 - 7 电源开关 (O=关, I=开)

- B-**
OS-2130D Pro
- 1 钱柜插槽
 - 2 电源连接插槽
 - 3 USB 端口
 - 4 RS232 串行端口

- C-**
- 1 纸卷供应端
 - 2 闭锁卡条
 - 3 打印头模组
 - 4 标签引导器

Español

- A-**
- 1 Cubierta de arriba
 - 2 Salida de Papel
 - 3 Botón
 - 4 Indicador de energía
 - 5 Indicador READY
 - 6 Botón FEED (Alimentación)
 - 7 Interruptor de energía (O = Off, I = A)

- B-**
OS-2130D Pro
- 1 Puerto para cajero
 - 2 Conector de alimentación
 - 3 USB
 - 4 RS232

- C-**
- 1 Soporte de suministro de papel
 - 2 Seguro de liberación
 - 3 Cabezal de impresión
 - 4 Guías del papel

Français

- A-**
- 1 Couverture
 - 2 Papier de sortie
 - 3 Bouton
 - 4 Indicateur d'alimentation
 - 5 Prêt Indicateur
 - 6 Bouton d'alimentation
 - 7 Power (O = Off, I = On)

- B-**
OS-2130D Pro
- 1 Port tiroir-caisse
 - 2 Connecteur d'alimentation
 - 3 USB
 - 4 Serial RS232

- C-**
- 1 Support l'approvisionnement en papier
 - 2 Levier de sortie
 - 3 Tête d'impression
 - 4 Guides des médias

Deutsch

- A-**
- 1 Deckel
 - 2 Papier Öffnung
 - 3 Deckel Taste
 - 4 POWER-LED
 - 5 Zustandsanzeige
 - 6 FEED-Taste
 - 7 Netzschalter (O = AUS, I = An)

- B-**
OS-2130D Pro
- 1 Kassenschublade Anschluß
 - 2 Zustandsanzeige
 - 3 USB
 - 4 RS232 seriell

- C-**
- 1 Etikettenrollenhalter
 - 2 Knöpfe zum Entrasten der Halterung
 - 3 Druckkopf-Modul
 - 4 Media-Guides

Português

- A-**
- 1 Tampa Superior
 - 2 Papel tomada
 - 3 Pulsante
 - 4 Indicador de Energia
 - 5 Indicador de Funcionamento
 - 6 Tecla de avanço de papel
 - 7 Interruptor Ligar/ Desligar (O= Desligar, I = Ligar)

- B-**
OS-2130D Pro
- 1 ATM do Porto
 - 2 Indicador de Funcionamento
 - 3 USB
 - 4 Série RS232

- C-**
- 1 Suporte do rolo de papel
 - 2 Manetes para libertar papel
 - 3 Módulo da cabeça de impressora
 - 4 Guia de papel

Italia

- A-**
- 1 Coperchio
 - 2 Uscita carta
 - 3 Pulsante
 - 4 LED Accensione
 - 5 LED Pronto
 - 6 Pulsante avanzamento
 - 7 Interruttore accensione (O = Off, I = On)

- B-**
OS-2130D Pro
- 1 Cassetto porta
 - 2 LED Pronto
 - 3 USB
 - 4 Seriale RS232

- C-**
- 1 Supporto rotolo
 - 2 Leve di rilascio
 - 3 Modulo Testina di stampa
 - 4 Guide carta

Turkish

- A-**
- 1 Üst Kapak
 - 2 Kağıt Çikisi
 - 3 Düğmesi
 - 4 Güç LED'i
 - 5 Hazır LED'i
 - 6 İlerletme Düğmesi
 - 7 Açma/Kapatma Düğmesi

- B-**
OS-2130D Pro
- 1 Nakit Çekmece Port
 - 2 Hazır LED'i
 - 3 USB Girişi
 - 4 Seri Port Girişi

- C-**
- 1 Etiket çubuğu
 - 2 Serbest bırakma Tırnakları
 - 3 Termal Yazıcı Kafası
 - 4 etiket sabitleme aparatı

Russian

- A-**
- 1 Верхняя крышка
 - 2 Слот выхода бумаги
 - 3 Защелка крышки
 - 4 Индикатор питания
 - 5 Индикатор готовности к работе
 - 6 Кнопка подачи (проточки) ленты
 - 7 Кнопка включения питания (O = Выкл, I = Вкл)

- B-**
OS-2130D Pro
- 1 Порт денежного ящика
 - 2 Разъем питания
 - 3 USB порт
 - 4 COM порт (RS232)

- C-**
- 1 Держатель ленты
 - 2 Рычаги-защелки
 - 3 Печатающая головка
 - 4 Направляющие для ленты